




QUICK START GUIDE

Mount cell phone in top cradle by tightening the back knob.



Use side wingnut to adjust viewing angle.



Install top cell phone cradle with supplied bolt and wingnut


Insert power adapter into base and plug into a power source to charge (red status light will stop flashing when complete)

Note: You may also use your Quickshot Launch while it is plugged in for charging




Stroke Length button

Press rocker button to increase or decrease stroke length




Stroke Speed button

Press rocker button to increase or decrease stroke speed



Stroke Position



Power/
Start/
Pause

Stroke Position button

Press button on side of left grip to adjust position of stroke - base, shaft, or tip

Note: If you've set stroke length to the max setting, the stroke position will not change

Power/Start/Pause button

Power ON - Press and hold until device becomes active (about 3 sec.)

Start/Pause - Once device is active (lights begin flashing), press once to start. Press again at any time during use to pause movement.

Power OFF - Press and hold button to turn off Quickshot Launch (about 4 sec.)